

# Update X-25M Firmware

POWER QUOTIENT INTERNATIONAL CO.,LTD.  
14F, No.16, Jian Ba Road Chung Ho City, Taipei, Taiwan, R.O.C.  
Tel :+886-2-8226-5288 Fax :+886-2-8226-5268-9



Please copy the data of the SSD first, it will be erased after update the firmware.

.Please follows the steps from the below:

1. Go to the Intel download website located


[http://downloadcenter.intel.com/Detail\\_Desc.aspx?agr=Y&ProdId=3044&DwnldID=18363&lang=zht](http://downloadcenter.intel.com/Detail_Desc.aspx?agr=Y&ProdId=3044&DwnldID=18363&lang=zht)

2. Create the ISO image CD-R

3. Insert the CD-R containing the ISO image into the R/W CD-ROM drive.

4. Use CD-ROM drive to boot (Picture 1)

4.1 Enter "y" and press **Enter**



4.2 Show "Do you accept these term of use?" Enter "y" and press **Enter**

5. **Scanning for Intel SATA SSDs** (Picture2)

5.1 Enter "y" and press **Enter**



6. **Warning screen**(Picture3)

6.1 Enter "y" and press **Enter**




# Update X-25M Firmware

POWER QUOTIENT INTERNATIONAL CO.,LTD.  
14F, No.16, Jian Ba Road Chung Ho City, Taipei, Taiwan, R.O.C.  
Tel :+886-2-8226-5288 Fax :+886-2-8226-5268-9



## 7 Firmware Update Successful (Picture 4)



- 7.1 Remove the CD-ROM
- 7.2 Restart your computer
- 7.3 Update completed